

Lecture B2: Superconductive RF Cavity Fabrication

Home work

- Read the distributed materials (Wikipedia Nb, Ta) and check following items.
- Check the characteristics/parameters of niobium and tantalum.
- Check what kind of industries are using niobium and tantalum.