Analysis of the Magnetic shield for ILC Cavities

L. Monaco


INFN-Milano LASA


Magnetic Field Generation

Code: POISSON


•A uniform magnetic field has been generated with a solenoid.

- •The field magnitude is 1 on the axis.
- •The field is parallel to the cavity axis
- •The cavity is placed between 400 and 500 cm.






Ideal shield without gaps



Infinite inner shield


(shielding material: thickness = 3 mm; μ_r = 100000)



Uniform field distribution on cavity axis.


 $R_{inner/outer}(450cm) = 4.10^{-3}$

Outer ideal shield with gaps



- •inner shield
- •outer shield infinite with 10 cm overlap


(shielding material: thickness = 3 mm; μ_r = 100000)




Not uniform field distribution on cavity axis: two peaks corresponding to the inner shield borders (gaps)

 $R_{inner/outer}(gaps) = 0.35$ $R_{inner/outer}(450cm) = 4.10^{-3}$

Outer shield "closed" with gaps




Summary of the studied shield cases




From simulation, main results obtained with the inner shield (inserted in the Hetank) are:

- •The residual magnetic field in the center of the cavity is low (better with the "closed" solution)
- •The magnetic field sharply increases approaching the end of the inner shield (near 400 cm) both in the ideal and in the closed solution
- •Corresponding to the end of the inner shield a maximum (ideal case) or a flex (closed case) are present

The outer shield "closed" solution: with and without gaps



The outer shield "closed" solution: with and without gaps Comparing the two cases



we observe:

- •two maxima in the same position and of the same magnitude (because of the same external shield border position and dimension in both cases)
- •the flexes are not present with the external shield alone: the field is lower! •playing with the size of the external border give the possibility to lower the residual magnetic field in the cavity region

Better without the inner shield:

 No gaps means no 600 magnetic field peak or flex in the gap region!