JLab-ILC Polarized e-Source R&D

P. Adderley, J. Brittian, J.Clark, J. Grames, J. Hansknecht, M.Poelker, M. Stutzman, R. Suleiman

Students: A. Jayaprakash , J. McCarter, K. Surles-Law





ILC – unique polarized e-beam requirements

- High Average Current (100uA, ~ 50x SLC ave. beam current)
- High Bunch Charge
- Demanding Time Structure


JLab Expertise


- CEBAF: 10 years experience delivering 100+uA
- Leverage time/money spent building a new CEBAF load locked gun, many features well suited for ILC: improved vacuum, multiple photocathode samples, rapid photocathode replacement





What limits photogun lifetime?








Thomas Jefferson National Accelerator Facility ILC e-Source Kick-OFF Meeting, SLAC, September 24-25,



Topic #1: Improving Gun Vacuum




Measured pressure always much greater than predicted



Thomas Jefferson National Accelerator Facility





Outgassing Rate

- Orifice and Rate of Rise Methods
- Studied 304, 316L and 6061 Al
- Degreasing/solvent cleaning vs electropolishing/vacuum firing at 900C


	Preprocessing				In situ bake parameters		Outgassing Rate (Torr·L/s·cm ²)		
Chamber	t(h)	T(°C)	EP	Surface roughness		t(h)	T(°C)	Orifice Method	Rate of Rise Method
Old 304			no	3.7 µm		400	250	9.7x10 ⁻¹³	1x10 ⁻¹²
New 304			no	3.7 µm		180	250	1.9x10 ⁻¹²	2.5x10 ⁻¹²
EP 304	4	900	yes	2.1	μm	30 then 90	150 250		8.9x10 ⁻¹³

"Characterization of the CEBAF 100 kV DC GaAs Photoelectron Gun Vacuum System," M.L. Stutzman, et al., Nucl. Instrum. Meth. A, 574 (2007) p. 213-:





Benefit of EP and Vacuum Firing



- Electropolishing and vacuum firing provides low rate with fewer bakes
- Extremely low values (e.g., 10⁻¹⁴ to 10⁻¹⁵) reported in literature elude us
- Conclusion: We have the "industry-standard" outgassing rate ~ 1x10⁻¹² Torr·L/s·cm²




Thomas Jefferson National Accelerator Facility



Recent High Temperature Bake of JLab FEL Gun

316 LN Stainless Steel, Baked at 400°C for 10 days Vacuum inside, hot air outside, Strip heaters instead of hot air guns Outgassing rate: 1.49x10⁻¹³ Torr L/s cm²






Thomas Jefferson National Accelerator Facility



NEG Pump Speed




- Full NEG activation better than passive activation via bake
- NEG pump speed very good, at least at high pressure
- Conclusion: Can't explain reduced pump speed at low pressure a real effect? More likely an indication of gauge limitations





NEG Coating




NEG coating turns a gas source into a pump ~0.02 L/s-cm² : Modest pump speed can be improved



Thomas Jefferson National Accelerator Facility




New CEBAF load-locked gun



Key Features:


- Smaller surface area
- Electropolished and vacuum fired to limit outgassing
- NEG-coated
- Never vented
- Multiple pucks (8 hours to heat/activate new sample)
- Suitcase for installing new photocathodes (one day to replace all pucks)
- Mask to limit active area, no more anodizing

Jefferson Lab






Load Locked Gun and Test Beamline



1mA from High Polarization Photocathode*



Vacuum R&D Summary


- Limit outgassing via high temperature 400°C bakeout
 - Can chamber be vented and still maintain low outgassing rate following 150°C, 250°C bake?
- Construct gauge that can accurately measure pressure below 1x10⁻¹¹ Torr (modified Helmer gauge)
 STTR proposal?
- Improve NEG coating process, to boost pump speed per unit area.
 - 0.02 L/s-cm² versus 1 L/s-cm² reported in literature





Improve Lifetime with Larger Laser Spot?

(Best Solution – Improve Vacuum, but not easy)






Thomas Jefferson National Accelerator Facility




Lifetime with Large/Small Laser Spots



"Further Measurements of Photocathode Operational Lifetime at Beam Current > 1mA using an Improved 100 kV DC High Voltage_GaAs Photogun," J. Grames, et al., Proceedings Polarized Electron Source Workshop, SPIN06, Tokyo, Japan


Topic #2: Increasing Gun Voltage




Must Eliminate Field Emission

Cornell Technique, high pressure rinsing (B. Dunham ERL07)

Recent tests at JLab with shaped electrodes support Cornell results







Thomas Jefferson National Accelerator Facility



High Voltage R&D Summary

- Field Emission reduction via high pressure rinsing, and if necessary, using coatings
- Reduce complexity, cost and size of ceramic insulators. Exploit medical x-ray source technology
- Lifetime studies at injector test cave using duplicate load locked gun: observe improved lifetime at higher gun voltage
- Other reasons to increase gun voltage....





Topic #3: Cathode/Anode Design

We learned at CEBAF that it is extremely important to manage ALL of the extracted beam

 Anodized edge: beam from outside 5 mm active area can hit beampipe walls, degrade vacuum, reduce operating lifetime


A better way for ILC?


Suggest multivariate optimization of:

- Cathode/anode optic
- First few meters of beamline, including SHB









Goals of Multivariate Optimization

- Create cathode/anode optic with small aberration across large photocathode active area, with very little beam loss. What to optimize?
 - Size of cathode electrode diameter, size of photocathode active area
 - Size of laser beam: lowest possible current density but with adequate emittance
 - Cathode/anode shape for adequate focusing
 - Cathode voltage/gradient: higher voltage to reduce space charge and provide possibility of extracting higher peak current with more narrow laser pulsewidth, to reduce SHB requirements





JLab-ILC Polarized e-Source R&D

- Vacuum R&D on-going
- Lifetime measurements at high current and 225kV will begin soon
- Graduate student to learn technique of multivariate optimization
- •
- .
- •
- Begin scaling/modifying CEBAF load lock gun design for ILC parameters
- Jlab vested interest in ILC gun program push gun voltage



