

SPiDeR (Silicon Pixel Detector Research) at EUDET Telescope



- Sensor overview with lab results



- TPAC
- FORTIS

- Beam test 09



D. Cussans on behalf of
J.J. Velthuis, A. Caldarone
for the
SPIDER collaboration



Jaap Velthuis, University of Bristol

Sensors...



- TPAC is the sensor aimed at digital calorimetry
 - Tests with Fe55 and beam test
- FORTIS aimed at tracking
 - Tests with light, Fe55 and beam tests
- Cherwell:
 - The future

Jaap Velthuis, University of Bristol

TPAC: Digital Calorimetry


- Average number of charged particles in EM shower \propto incident energy
 - Fluctuations due to statistical nature of shower
- Average energy in sensitive layers \propto number of charged particles
 - Fluctuations due to angle of incidence, velocity and Landau spread
- Hence, number of charged particles is an intrinsically better measure than the energy deposited
 - Clearest with ideal calorimeter; no experimental effects
 - Energy deposited (“analogue”

Jaap Velthuis, Univers







Digital Calorimetry: Concept

- Can we measure the number of charged particles?
 - Possible to get close to the analogue ideal resolution with low noise electronics
- Can we get anywhere near the ideal resolution for the digital case?
 - Make pixellated detector with small pixels
 - Probability of more than one charged particle per pixel can be made small
 - Allows binary readout = hit/no hit
- EM shower density $\sim 100/\text{mm}^2$ in core
 - Need pixels $\sim 50\mu\text{m}$
 - Results in huge number of pixels in a real ECAL $\sim 10^{12}$ pixels



Jaap Velthuis, University of Bristol

TPAC Pixel



PO
M1


- Gain 136 μ V/e
- Noise 23e⁻
- Power 8.9 μ W
- 150ns "hit" pulse wired to row logic
- Shaped pulses return to baseline

- 50 μ m pixel
- 4 diodes
- 160 transistors
- 27 unit capacitors
- 1 resistor (4Mohm)
- Configuration SRAM
 - Per Pixel Mask
 - Comparator trim (6 bits)

NW
DPW

Jaap Velthuis, University of Bristol

TPAC Fe55




- Primary ^{55}Fe peak gives calibrated gain of $128\mu\text{V}/e^-$
- Width of ^{55}Fe peak gives noise of $27e^-$
- See $K\alpha$ and $K\beta$ clearly separated

Jaap Velthuis, University of Bristol

TPAC beam test

- TPAC in beam tests
 - 120 GeV π & 20–120 GeV e^-
 - 6 TPAC sensors (layers) in stack
 - 170k pixels in total
 - 1cm x 1cm active area
 - Three scintillators/PMTs installed
 - Used to tag time of particles within bunch trains
- Data seems good
 - Scintillators/PMTs give good time tags for particles
 - Events were seen in all layers




USB-based DAQ setup on H6B beam line at CERN

Jaap Velthuis, University of Bristol

TPAC beam test

- TPAC in beam tests
 - 120 GeV π & 20–120 GeV e^-
 - 6 TPAC sensors (layers) in stack
 - 170k pixels in total
 - 1cm x 1cm active area
 - Three scintillators/PMTs installed
 - Used to tag time of particles within bunch trains
- Data seems good
 - Scintillators/PMTs give good time tags for particles
 - Events were seen in all layers



Jaap Velthuis, University of Bristol


FORTIS

- FORTIS is the first 4T MAPS for Particle Physics
 - 3T CMOS
 - Simple architecture
 - Readout and charge collection area are the same
 - 4T CMOS
 - Three additional elements
 - Readout and charge collection area are at different points

Jaap Velthuis, University of Bristol

FORTIS



- FORTIS is the first 4T MAPS for Particle Physics
 - 3T CMOS
 - Simple architecture
 - Readout and charge collection area are the same
 - 4T CMOS
 - Three additional elements
 - Readout and charge collection area are at different points



Jaap Velthuis, University of Bristol

FORTIS



- FORTIS is the first 4T MAPS for Particle Physics
 - 3T CMOS
 - Simple architecture
 - Readout and charge collection area are the same
 - 4T CMOS
 - Three additional elements
 - Readout and charge collection area are at different points



Jaap Velthuis, University of Bristol

FORTIS


- FORTIS is the first 4T MAPS for Particle Physics
 - 3T CMOS
 - Simple architecture
 - Readout and charge collection area are the same
 - 4T CMOS
 - Three additional elements
 - Readout and charge collection area are at different points



Jaap Velthuis, University of Bristol

4T Pixel Advantages


- Low Noise
 - readout node separated from charge collection area
 - The reset noise and fixed pattern noise (FPN) can be removed by in-pixel correlated double sampling (CDS)
- High Conversion Gain
 - Charge is collected on large diode then transferred to the floating diffusion
 - Large C gives fast and complete charge collection
 - Small C yields large gain



Jaap Velthuis, University of Bristol

4T Pixel Advantages


- Low Noise
 - readout node separated from charge collection area
 - The reset noise and fixed pattern noise (FPN) can be removed by in-pixel correlated double sampling (CDS)
- High Conversion Gain
 - Charge is collected on large diode then transferred to the floating diffusion
 - Large C gives fast and complete charge collection
 - Small C yields large gain



Jaap Velthuis, University of Bristol

4T Pixel Advantages


- Low Noise
 - readout node separated from charge collection area
 - The reset noise and fixed pattern noise (FPN) can be removed by in-pixel correlated double sampling (CDS)
- High Conversion Gain
 - Charge is collected on large diode then transferred to the floating diffusion
 - Large C gives fast and complete charge collection
 - Small C yields large gain



Jaap Velthuis, University of Bristol

4T Pixel Advantages


- Low Noise
 - readout node separated from charge collection area
 - The reset noise and fixed pattern noise (FPN) can be removed by in-pixel correlated double sampling (CDS)
- High Conversion Gain
 - Charge is collected on large diode then transferred to the floating diffusion
 - Large C gives fast and complete charge collection
 - Small C yields large gain



Jaap Velthuis, University of Bristol

4T Pixel Advantages



- Low Noise
 - readout node separated from charge collection area
 - The reset noise and fixed pattern noise (FPN) can be removed by in-pixel correlated double sampling (CDS)
- High Conversion Gain
 - Charge is collected on large diode then transferred to the floating diffusion
 - Large C gives fast and complete charge collection
 - Small C yields large gain



Jaap Velthuis, University of Bristol

4T Pixel Advantages


- Low Noise
 - readout node separated from charge collection area
 - The reset noise and fixed pattern noise (FPN) can be removed by in-pixel correlated double sampling (CDS)
- High Conversion Gain
 - Charge is collected on large diode then transferred to the floating diffusion
 - Large C gives fast and complete charge collection
 - Small C yields large gain



Jaap Velthuis, University of Bristol


Deep Pwell

- Problem in MAPS:
 - PMOS electronics need Nwell
 - Nwell acts as charge collection diode
 - So can't make PMOS without losing huge amount of Q
- New development: make deep pwell with Nwell inside → can do CMOS
 - Road to data processing in pixel



Jaap Velthuis, University of Bristol


Substrate Resistivity



- High resistivity (intrinsic) silicon enlarges the depletion region to fully occupy the pixel
 - Majority of deposited charge now falls in a depletion region and is collected by electric field
 - Improved charge collection efficiency
 - Faster charge collection (drift vs diffusion)
- Some FORTIS have high res


Jaap Velthuis, University of Bristol

FORTIS Results




Jaap Velthuis, University of Bristol

FORTIS Results




Jaap Velthuis, University of Bristol

FORTIS Results




Jaap Velthuis, University of Bristol

FORTIS Results




Jaap Velthuis, University of Bristol

FORTIS Results



Jaap Velthuis, University of Bristol


FORTIS results



- ^{55}Fe Photons (preliminary)
 - Conversion gain = $56 \mu\text{V}/e^-$
 - Noise (from dark fwhm) = $7.7e^-$


Jaap Velthuis, University of Bristol

Some test beam pictures




Jaap Velthuis, University of Bristol

Some test beam pictures




Jaap Velthuis, University of Bristol

Some test beam pictures




Jaap Velthuis, University of Bristol

We see hits...




Jaap Velthuis, University of Bristol

We see hits...




Jaap Velthuis, University of Bristol

Raw signals




Jaap Velthuis, University of Bristol

Raw S/N for each pixel




Jaap Velthuis, University of Bristol

Pixel Noise



Jaap Velthuis, University of Bristol


Cluster signal











- Corresponds to $S/N \sim 50$
- Data analysis just started
- Still need to match up with telescope





Jaap Velthuis, University of Bristol





Analysis scheme



















The future: Cherwell



- Uses INMAPS plus 4T to achieve
 - 100% fill factor with integrated sensor and readout electronics
 - Incorporation of complex logic within a pixel
 - Investigation of data reduction/clustering
 - Low noise using transfer gate, CDS and in-pixel amplification

Jaap Velthuis, University of Bristol



Future plans

- Complete beam test analysis for FORTIS and TPAC
- Test all FORTIS and TPAC variants in the lab
- Test results will drive DECAL and CHERWELL architectures
- Perform beam test at DESY with TPAC
- Waiting for next April fools day...

Jaap Velthuis, University of Bristol